

## ACS SmartAcess (for Android)



User Guide V1.01



## **Table of Contents**

1.0.	Introduction3
2.0.	For Android4



## 1.0. Introduction

ACS SmartAccess is an application that demonstrates Access Control usage for ACS Bluetooth Readers. To fully access the application's features, connect an ACS Bluetooth Reader and use with a smart card.

Supported smart card readers are ACR3901U-S1 Secure Bluetooth Contact Card Reader, ACR3901T-W1 Secure Bluetooth SIM-sized Contact Card Reader and ACR1255U-J1 Secure Bluetooth NFC Reader. Supported smart cards types are ACOS3, Mifare Classic®1, and FeliCa.

<sup>&</sup>lt;sup>1</sup> MIFARE and MIFARE Classic are trademarks of NXP B.V.



## 2.0. For Android

- 1. Download ACS SmartAccess app from Google Play, or by clicking on the link below: https://play.google.com/store/apps/details?id=com.acs.acssmartaccess&hl=en
- 2. Turn on the Bluetooth mode of your device to make it discoverable.
  - a. For ACR3901U-S1, slide the toggle switch to the right.



b. For ACR1255U-J1, slide the toggle switch to the right.



c. For ACR3901T-W1, press the button to turn on the reader.



- 3. Turn on your device's Bluetooth by going to **Settings | Bluetooth**.
- 4. Open **ACS SmartAccess** app and click the button below for an interactive guide on how to use the app.